

**How to Measure a Treadmill Fan / Drive / Motor Belt - Guide Only**  
[www.runningbelts.com.au](http://www.runningbelts.com.au)

- 1) Remove treadmill from power point
- 2) Remove Motor Cover.
- 3) Look for size on drive belt first ( e.g PJ483 or 190J )



- 4) Measuring the length. Mark a line on it with a marker. Now measure 100mm at a time. Till you come back to the first mark. Now add up all the 100's plus last measurement ( eg 533 mm ) ( 21 inches )
- 5) Look on the inside to see how many ribs there are and count the grooves. Most domestic treadmills will have 6-7 grooves.



**Remember to double check your measurements to avoid delays and fitting problems.**  
**Now compare your measurements with the table below to order the correct size replacement fan/drive belt**  
**Common Fan Drive Motor belt size list**  
**(Pick belt closest to your measurement for replacement)**

<b>PJ</b>	<b>J</b>	<b>Millimetres (mm)</b>	<b>Inches (in)</b>
PJ406	160J	406	16
PJ432	170J	432	17
PJ457	180J	457	18
PJ483	190J	483	19
PJ495	195J	495	19.5
PJ508	200J	508	20
PJ533	210J	533	21
PJ559	220J	559	22
PJ584	230J	584	23
PJ610	240J	610	24